



Unit: mm(approx. inch)

● Bottom Process Connection (Installation code B)



● Terminal Configuration



● Terminal Wiring

| | |
|-----------------------------|---|
| SUPPLY $\frac{+}{-}$ | Power supply and output terminal |
| CHECK $\frac{+}{-}$ | External indicator(ammeter) terminal*1 |
| PULSE $\frac{+}{-}$ | Pulse or status contact output terminal |
| $\frac{\text{—}}{\text{—}}$ | Ground terminal |

*1: When using an external indicator or check meter, the internal resistance must be 10 Ω or less.