



# Instruction Manual

# Model BA10 Connection Box

## 1. Cable(s) between sensor(s) - connection box

When the sensor cables are numbered they can be connected to the corresponding numbers of the terminal block. The reverse of this page shows the connection diagrams for all parameters.

## 2. Cable between connection box - transmitter

The cable type WF10 is recommended as a connection between box and transmitter. The cores and screens of the cable must be connected to the corresponding numbers of the terminal block to which the sensor cable(s) is connected. Fig. 4 shows the connections of the WF10 cable.

## 3. Accessories (enclosed in a packet in the connection box)

The packet contains the following items:

- 2 glands PG16 which can be screwed in the holes of the box.
- 1 grommet which can be mounted in a gland to provide a waterproof sealing when 3 electrode cables and earth connection are used (see fig. 1),
- 1 coupling for hose connection (alternative to fig. 2).

The fixing dimensions are on the back of the case.





Fig. 1. Connection box BA10

<p><b>YOKOGAWA ELECTRIC CORPORATION</b>  <b>World Headquarters</b>          9-32, Nakacho 2-chome, Musashino-shi          Tokyo 180-8750          Japan  <a href="http://www.yokogawa.com">www.yokogawa.com</a></p>	<p><b>YOKOGAWA ELECTRIC ASIA Pte. LTD.</b>          5 Bedok South Road          Singapore 469270          Singapore  <a href="http://www.yokogawa.com/sg">www.yokogawa.com/sg</a></p>	<p>Yokogawa has an extensive sales and distribution network. Please refer to the European website (<a href="http://www.yokogawa.com/eu">www.yokogawa.com/eu</a>) to contact your nearest representative.</p>
<p><b>YOKOGAWA CORPORATION OF AMERICA</b>          2 Dart Road          Newnan GA 30265          USA  <a href="http://www.yokogawa.com/us">www.yokogawa.com/us</a></p>	<p><b>YOKOGAWA CHINA CO. LTD.</b>          3F Tower D Cartelo Crocodile Building          No.568 West Tianshan Road Changning District          Shanghai, China  <a href="http://www.yokogawa.com/cn">www.yokogawa.com/cn</a></p>	
<p><b>YOKOGAWA EUROPE BV</b>          Euroweg 2          3825 HD AMERSFOORT          The Netherlands  <a href="http://www.yokogawa.com/eu">www.yokogawa.com/eu</a></p>	<p><b>YOKOGAWA MIDDLE EAST B.S.C.(c)</b>          P.O. Box 10070, Manama          Building 577, Road 2516, Busaiteen 225          Muharraq, Bahrain  <a href="http://www.yokogawa.com/bh">www.yokogawa.com/bh</a></p>	



**YOKOGAWA** ◆