



HART®  
Communicating Products  
include:

YEWFO  
Vortex Shedding Flowmeters

•  
ADMAG  
Magnetic Flowmeters

•  
DPharp  
Digital Pressure Transmitters

•  
UNIDELTA  
Pressure Transmitters

•  
YT200  
Temperature Transmitters

DPharp EJA Series  
**HART** Communicating  
Pressure Transmitters



Basic Programming  
Pocket Reference Guide

**YOKOGAWA** ◆

2 Dart Road  
Newnan, GA 30265  
770.254.0400

#### ERROR CODES

Integral Display	Brain Terminal Display	Action or Cause
Er.01	CAP MODULE FAULT	Replace Capsule
Er.02	AMP MODULE FAULT	Replace Amplifier
Er.03	OUT OF RANGE	Check Input Range
Er.04	OUT OF SP RANGE	Static Pressure > Specified Range
Er.05	OVER TEMP (CAP)	Process Temp Too High or Low
Er.06	OVER TEMP (AMP)	Ambient Temp Too High or Low
Er.07	OVER OUTPUT	Change Input or Range Setting
Er.08	OVER DISPLAY	Change Input or Display Conditions
Er.09	ILLEGAL LRV	Change Low Range Value
Er.10	ILLEGAL HRV	Change High Range Value
Er.11	ILLEGAL SPAN	Change Span Value
Er.12	ZERO ADJ OVER	Readjust Zero Point

