

Model
375


Error Codes

Integral Display	Action or Cause	Integral Display	Action or Cause
AL.01 CAP ERR	REPLACE CAPSULE	AL.38 SP LOW	STATIC PRESSURE EXCEEDS RANGE
AL.02 AMP ERR	REPLACE AMPLIFIER	AL.39 TMP HI	TEMP EXCEEDS LIMIT-HIGH
AL.10 PRESS	CHECK INPUT RANGE	AL.40 TMP LO	TEMP EXCEEDS LIMIT-LOW
AL.11 ST PRESS	STATIC PRESSURE->SPECIFIC RANGE	AL.50 P LRV	ILLEGAL LRV
AL.12 CAP TEMP	PROCESS TEMP TOO HI OR LOW	AL.51 P URV	ILLEGAL HRV
AL.13 AMP TMP	AMBIENT TEMP TOO HI OR LOW	AL.52 P SPN	VALUE OUTSIDE TRANSMITTER RANGE
AL.30 RANGE	CHANGE INPUT OR RANGE SETTING	AL.53 P ADJ	VALUE OUTSIDE TRANSMITTER RANGE
AL.31 SP RNG	CHANGE INPUT OR RANGE SETTING	AL.54 SP RNG	ILLEGAL LRV
AL.35 P HI	CHECK INPUT PRESSURE-TO HIGH	AL.55 SP ADJ	CHANGE SPAN VALUE
AL.36 P LOW	CHECK INPUT PRESSURE-TO LOW	AL.60 SC CFG	CONFIGURATION ERROR-CHECK SETTINGS
AL.37 SP HI	STATIC PRESSURE EXCEEDS RANGE	AL.79 OV DISP	DISPLAYED VALUES EXCEED LIMIT

A Yokogawa Commitment to Industry

vigilance.TM

Our People
make the difference



**ENGAGE
DELIVER
COLLABORATE
ACT**

Yokogawa Corporation of America

2 Dart Road
Newnan, GA 30265
770.254.0400

DP harp EJXTM
HART  **Communicating Pressure Transmitters**



Basic Programming
Pocket Reference Guide

YOKOGAWA 

EJX HART COMMUNICATIONS PROGRAMMING GUIDE

